

New Updates on your Pacor Client (Version 3.70.654) (May 25 2006)

Please take backup of your older version software.

Unzip all bmp files into your System path and also update your Pacor Client Exe (whichever key you are using).

Check on Start -> About to check your newer version.(Version 3.70.654 May 25 2006)



In New version Operator can create queue for Optimization tasks.


NEW UPDATE: Adding of “Auto Optimization”

BENEFITS


1. After optimization software will automatically save the projects.
2. At a Time you can optimize the stone with different algorithm on same .mmd
3. Optimize the stone and moving all the projects from one folder to another automatically.

1.After Optimization software will Automatically save the Project.


1. Open the Optimization task list... by Click on Start -> Optimization task list...
2. You will get following screen



- 3.
4. Click On “Add file...”
5. Select your folder and .mmd file.



- 6.
7. Press On “Open”.
8. You will get following screen




9.

10. Select optimization method, shape and Cut grade.

11. Select Save option.


12. i.e. suppose you select **_auto** in Save option, then n1.mmd will automatically save as n1_001.mmd, and if you select **_1, _2**, then software will automatically save as n1_1.mmd

13. Then press “OK” ,program will start optimization and screen as follows.



NOTE: Green Symbol shows as process is over.

Red indicator shows as Process is running and yellow indicator shows as this process is pending on queue.




If you want to see optimization result then click on green button and you can load this project by pressing on Load button.

2. At a Time you can optimize the stone with different algorithm on same .mmd


1. Repeat above step no 1 to 13 and again press on “Add file..” and once again repeat step no 5 to 13 with different Optimization method.

3. Optimize the stone and moving all the projects from one folder to another automatically.

1. Open the Optimization task list... by Click on Start -> Optimization task list...
2. You will get following screen



3. Click on “Add task..”, then you will get following screen.



4. Click on Browse button and select your input path and mmd & also select Output path (In output path there should be at least one .mmd required)

QURERIES:

1. Default color, clarity and pricelist selection in task list. Currently we choose from marking out panel for each and every time, but when we select same mmd for different method then problem occur example (jb)
2. If I want to save the mmd with different name....
3. When shape selection from task list, we can not see individual shape check box in group of cutting .
4. When we using no 3 facility then why need .mmd in output folder.